

# Display and Power Supply Unit

Flowview 2S-II



Flowview 2S-II is a display unit for the flow rates of a maximum of two Flowmax drink meters and their voltage supply. The Flowview 2S-II is supplied with power via an already connected Schuko plug and a customer-side 230 V/AC socket.

The Flowview 2S-II contains the power supply for 1 or 2 Flowmax 30S via circular connector. The counting stops of the dispensing volumes are displayed via a two-line display.

A key switch allows you to switch from the operating mode to the cleaning mode.

The two counters can be reset to zero each other via the keyboard.

Display in liters with 5 digits in front of the point and 1 after.

SI 002E/FV2S-II/04.17

## Housing

Material	ABS
Colour	Light grey, similar to RAL 7035
Cover seal	Silicone
Connections	1 main plug for 230 VAC power supply, cable length 1,5 m, 2 M12 round connectors, 5-pins
Protection class	IP65
Dimensions incl. connections H/W/T [mm]	100/80/57
Weight	250 g

## Display and keyboard

Display	2 x 16-characters, LCD, illuminated
Film keyboard	4 keys with pressure point
Key switch	to switch between cleaning and reset mode

## Electronics

Auxiliary power	230VDC, 5W
Miniature fuse	2A, time delay
Ambient temperature	-20...+60°C
Connections	2 x Flowmax

## Further information:

**MIB GmbH**  
Bahnhofstr. 35, D-79206 Breisach  
Tel: 0049 / (0 ) 7667 – 20 777 90  
Fax: 0049 / (0 ) 7667 – 20 777 99  
Mail: [info@mib-gmbh.com](mailto:info@mib-gmbh.com)  
Web: [www.flowmax.de](http://www.flowmax.de)

Technical subjects to be changed!

**MIB GmbH**  
Messtechnik & Industrieberatung